

# REFERENCE ONLY

# **OMNICRON 8000**

## **USER PROGRAMME**

### **PROG FUNCTION**

**USER CODE or 1234 (CLEAR FLASHING)**

**THEN PRESS:-**

- |                                |   |
|--------------------------------|---|
| <b>CHANGE USER CODE</b>        | <b>- 1 - ENTER NEW CODE</b>                     |
| <b>SELECT CHIME ZONES</b>      | <b>- 2 - ENTER ZONE NUMBERS - PROG FUNCTION</b> |
| <b>TEST SIREN &amp; STROBE</b> | <b>- 3 - PRESS 3 TO STOP TEST</b>               |

## **ENGINEER PROGRAMME**

### **PROG FUNCTION**

**ENGINEER CODE or 9999 (CLEAR & PA FLASHING)**

**THEN PRESS :-**

- |                                  |   |
|----------------------------------|---|
| <b>CHANGE ENGINEER CODE</b>      | <b>- 1 - ENTER NEW CODE</b>                     |
| <b>EXIT TIME</b>                 | <b>- 2 - ENTER NUMBER OF SECONDS</b>            |
| <b>ENTRY TIME</b>                | <b>- 3 - ENTER NUMBER OF SECONDS</b>            |
| <b>SIREN DURATION</b>            | <b>- 4 - ENTER NUMBER OF MINUTES</b>            |
| <b>SELECT E/E ZONES</b>          | <b>- 5 - ENTER ZONE NUMBERS - PROG FUNCTION</b> |
| <b>ALLOW/PREVENT ZONE OMIT</b>   | <b>- 6 - ENTER ZONE NUMBERS - PROG FUNCTION</b> |
| <b>KEYSWITCH QUICKSET</b>        | <b>- 7 - PRESS 1 - PROG FUNCTION</b>            |
| <b>LOCAL/FULL 24HR ALARM</b>     | <b>- 7 - PRESS 2 - PROG FUNCTION</b>            |
| <b>SILENT P.A</b>                | <b>- 7 - PRESS 3 - PROG FUNCTION</b>            |
| <b>ENGINEER ONLY RESET</b>       | <b>- 7 - PRESS 4 - PROG FUNCTION</b>            |
| <b>SELECT FIRE ZONE</b>          | <b>- 7 - PRESS 5 - PROG FUNCTION</b>            |
| <b>SELECT WALKTHROUGH ZONES</b>  | <b>- 8 - ENTER ZONE NUMBERS - PROG FUNCTION</b> |
| <b>FINAL DOOR QUICKSET</b>       | <b>- 9 - PRESS 1 - PROG FUNCTION</b>            |
| <b>SW+ FACILITY</b>              | <b>- 9 - PRESS 2 - PROG FUNCTION</b>            |
| <b>DOORLOCK TO ARM/DISARM</b>    | <b>- 9 - PRESS 3 - PROG FUNCTION</b>            |
| <b>LOCAL/FULL FIRE ALARM</b>     | <b>- 9 - PRESS 4 - PROG FUNCTION</b>            |
| <b>KEYSWITCH FULL/PART GUARD</b> | <b>- 9 - PRESS 5 - PROG FUNCTION</b>            |
| <b>SYSTEM RESET</b>              | <b>- 0 -</b>                                    |

## **REMOTE KEYBOARD PROGRAMME**

### **SETUP PROGRAMME**

**PROG FUNCTION**

**ENGINEER CODE or 9999**

**PRESS 9**

**PRESS 5**

**PROG FUNCTION**

**PRESS RESET TWICE**

### **ZONE OMIT PROGRAMME**

**ENTER USER CODE or 1234**

**PRESS ZONE OMIT**

**ENTER ZONE NUMBERS**

**PRESS ZONE OMIT**

**PRESS RESET**

**ENTER USER CODE or 0**

**PRESS P**

**ENTER NEW CODE**

**PRESS P**